

Clemson Roku Set Up

WIRED CONNECTION

This guide outlines how to register your Roku with NetReg at Clemson.
You must complete these steps before activating your Stream 2 account.

what you need

Roku 2+ Streaming Player
HDMI Cable
Ethernet Cable
TV

register with NetReg

- 1 Go to <https://netreg.clemson.edu>.
- 2 Log in with your University username and password.
- 3 Select **Add Registration** on the left of the screen.
- 4 Enter the **MAC Address** for the Roku device in the format XX:XX:XX:XX:XX:XX in the box labeled Hardware Address.

To obtain the Ethernet (wired) MAC address for your Roku device:

On the back of the player - it's a set of six 2-digit pairs separated by colons, e.g. 00:0D:0A:1H:3G:5C. One set is for the Ethernet connector (wired) and the other is for the wireless connection (WiFi).

Alternatively, with your Roku connected to your TV, from the Roku home screen, **select settings > player info** from your Roku, and the addresses will be listed on-screen.

If you still don't see the address, with your Roku remote hit the **Home button 5X**, **FF button 3X**, and **Rewind button 2X** a screen should appear. The MAC addresses will be listed on-screen.

- 5 Enter the **Device Description**.
- 6 Select **I Agree** at the bottom of the screen.
- 7 **Log Out** by closing the browser window.

add the Stream2 channel

- 1 From your **TV**, open **Roku**.
- 2 On the **Home Screen** select **Add Channels**.
- 3 Search for **Apogee Stream2** in the channel store
- 4 Select **Add Channel**.

activate your Roku device

- 1 Open the **Stream2** app on your TV.
- 2 Type in **Clemson University** for your institution.
- 3 Log in using your **University username and password**.
- 4 Once logged in, follow the directions to **Activate the Device**.

For additional assistance with device registration, visit MyCampusVideo.com/support or call 855-377-5151